

Installation of your Handspray



1 Most toilets have a flex pipe.



2 Remove flex pipe.



4 Fit handspray hose to water diverter, ensuring you insert black washer.



3 Place dual check on tap, ensuring you insert into the bottom of the backflow dual check.



5 Fit water diverter to Cistern, ensuring you insert Black Washer.



6 Connect Flex Pipe.



Now all that's left to do is screw on the Handspray holder to the wall and place your Handspray into it.

If you require any further assistance please do not hesitate to contact The Bidet Shop on 1800 243 387 and talk with our friendly staff today!

Operation of your Handspray



The Handspray water diverter has been designed with your safety in mind.

In position 1 all water supply to the Cistern and Handspray is **shut off**.

In position 2 water supply is to the Cistern **only**.

When you are **not using** the Handspray please place the water diverter into position 2. When you are about to use your Handspray turn the tap to adjust the waterflow for your personal comfort, when finished place back to position 2, the Cistern only position.

The[®]
BIDET
SHOP